



LEADSCREW ASSEMBLY

ITEM NO.	PARTS NO.	DESCRIPTION	ITEM NO.	PARTS NO.	DESCRIPTION
1	2004	Jam Nut (3 Req.)	16	3005-1	Stop Screw (4 Req.)
2	2004-1	Spring Washer (3 Req.)	17	3025-2	Socket Screw (4 Req.)
3	H2018	Ball Crank Handle (3 Req.)	18	3025-3	Washer (4 Req.)
4	2016	Dial Lock Nut (3 Req.)	19	3020-2A	Cross Feed Nut
5	2012	Dial with 200 Graduations (3 Req.)	20	H3025	Feed Nut Bracket
6	2014	Dial Holder (3 Req.)	21	3020-2B	Cross Feed Nut
7	2036	Socket Cap Screw (6 Req.)	22	3025-1	Flat Head Socket Screw (6 Req.)
8	2011	Bearing Retainer Ring (2 Req.)	23	3024	Socket Cap Screw (4 Req.)
9	2008	Grease Seal Ball Bearing 6204# (5 Req.)	24	2002	Longitudinal Feed Screw 50"
10	2010	Washer (2 Req.)	25	2006	Bearing Bracket (2 Req.)
11	2026	Socket Cap Screw (12 Req.)	26	3020-1A	Long Feed Nut
12	2027	Roll Pin (8 Req.)	27	3020-1B	Long Feed Nut
13	H3002	Cross Feed Screw for 13 $\frac{3}{4}$ " Knee	28	5016-1	Plate (3 Req.)
14	2003	Key (3 Req.)	29	5032	Round HD Drive Screw (6 Req.)
15	3005	Cross Feed Bearing Bracket	30	H2018 -1	Ball Crank Handle Grip (3 Req.)